



English

norcool
cold by nature




OPERATING & INSTALLATION INSTRUCTIONS



CAVE CIGAR



Please visit www.norcool.no for operating & installation instructions in other languages.



CAVE CIGAR

- 1. Important Information..... 6
- 2. Installation..... 8
- 3. Operating Instructions 10
- 4. Cleaning & maintenance..... 11
- 5. Cigar storage guide..... 12
- 6. Troubleshooting..... 13

Before first use

- Read and follow all the instructions below even if you feel you are familiar with the appliance.
- Remove the packing and make sure that the appliance is intact. If in doubt do not use the appliance and contact the manufacturer. Do not leave packaging materials such as bags and staples within reach of children.
- Dispose of packaging carefully and with consideration for the environment.

Safety information & warnings



When using any electrical appliance, basic safety precautions must be followed in order to reduce the risk of fire, electrical shock and/or injury to persons or property. Be sure to read all instructions before using this appliance and observe the following safety tips:



Attention: To prevent the risk of child entrapment, do not allow children to operate, play with, or crawl inside the unit. If the unit will not be used for an extended period of time, remove the door and leave the shelves in place so that children cannot crawl inside. Also, remove the door when disposing of the unit.

Children aged from 3 to 8 years are allowed to load and unload refrigerating appliances.

To avoid contamination of food, please respect the following instructions:

- Opening the door for long periods can cause a significant increase of the temperature in the compartments of the appliance.
- Clean regularly surfaces that can come in contact with food and accessible drainage systems.
- Clean water tanks if they have not been used for 48 h; flush the water system connected to a water supply if water has not been drawn for 5 days
- If the refrigerating appliance is left empty for long periods, switch off, defrost, clean, dry, and leave the door open to prevent mould developing within the appliance.

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.

Children shall not play with the appliance.

Cleaning and user maintenance shall not be made by children without supervision.

Never clean the appliance parts with flammable fluids, as the fumes can create a fire hazard or explosion. Do not store or use gasoline or any other flammable vapors and liquids near this or any other appliance.

Do not store perishable foods in the cigar cooler, as the interior temperature will not be low enough to prevent food spoilage.

Shock Hazard - Electrical Grounding Required



This cooler should be properly grounded for your safety. Improper use of the grounded plug can result in electrical shock.


If the power cord appears to be damaged, have it replaced by an authorized service center.

Never cut or remove the ground wire from the supplied power cord. Never allow the product to be connected to an extension cord permanently.

The cord should be secured behind the cooler. Also, to prevent accidental injury, do not expose or dangle the cord.

Parts list

1. Drawer
2. Hygrometer
3. Door
4. Shelf



2. Installation

This cooler is a freestanding unit and should not be installed inside a cabinet or other built-in enclosure.

For proper ventilation, allow 130 mm clearance between the back of the unit and any adjacent walls.

Before operating your cigar cooler for the first time, follow these steps:

- Before connecting the unit to a power source, allow it to stand upright for approximately 2 hours. This will reduce the possibility of any system malfunctions which may have occurred from handling during transportation. Clean the interior surface of the unit with lukewarm water and a soft cloth but do not get the wood wet.
- Place the cooler on a level surface that will be strong enough to support the unit when it is fully loaded. To level your cooler, adjust the front feet located at the bottom of the unit.
- Never place the appliance with the front edge along the edge of a table top or shelf, because there is a risk of the appliance tipping forwards and falling if the door compartments is overloaded. Take care to ensure that there is sufficient space in front of the appliance.
- Install the cooler away from direct sunlight and heat sources such as stoves, heaters, or radiators. Direct sunlight may affect the unit's acrylic coating, and nearby heat sources can increase electrical consumption. Extreme cold or hot ambient temperatures may also prevent proper performance.
- Please note: this cooler is only designed for home use, and is not designed to be placed in a garage, basement, or outdoor area.

Factory odor removal

Wash the interior of the cooler with a mild detergent and warm water. Make sure to not get the wood wet. Leave the door open and allow it to air dry thoroughly. If a "plastic" smell persists, place a dish of baking soda in the unit or stuff the cooler with newspapers overnight. When finished, let the unit run a full day to complete the airing out process.

Drawer setup

The drawers and shelves included with this cooler are designed to sit flush with the front edge of the cabinet. This will allow air to circulate freely through the unit.

When inserting the drawers and shelves, avoid pushing them all the way against the rear wall of the cabinet.

Seasoning your cigar cooler

It is best to season your wood shelves and drawers before adding your cigars so that the wood is at an ideal relative humidity (RH) and does not absorb humidity from your cigars. To season your new cigar cooler :


1. Add distilled water to the included moisture container or add a sponge that is damp with distilled water. Make sure that the water is not touching the wood directly or this may damage the wood.
2. Allow the moisture container, or other humidity-adding device, to sit in the cooler until it reaches a relative humidity of 5 % higher than your preferred level. This process may take as long as 3 days but is the best way to ensure your cigars stay optimal.
3. Once the cooler reaches this mark, you can begin to add cigars. You may add a few at a time in order to monitor the RH and make sure it stays at a level you want it at. If it drops too much, you can use the same seasoning method to bring it back up.

During this entire process, it is recommended to not open the door unnecessarily, as this lets moisture escape and can delay the process.

Operating environment

It is recommended to install the cooler in an area where the ambient temperature is between 18 °C-26 °C. If the ambient temperature is above or below the recommended ranges, the unit's performance may be affected, and extreme cold or hot conditions may cause the interior temperature to fluctuate. This will prevent the optimal range of 12 °C-23 °C from being reached. In addition, keep in mind that the temperature may fluctuate depending on whether the interior light is on or off, and how full the cooler is.

How to use the buttons on the display panel



Button functions:



Raise the desired temperatures.*



Lower the desired temperatures.*



Turn the light on or off

* The interior temperature can be adjusted in increments of 1 degree between 12 °C and 23 °C

After turning on the cigar cooler, the LED display will show the ambient temperature first, and then the set temperature.

Cleaning your cooler

To clean your cooler:

- Unplug the cooler and remove anything inside .
- Remove the shelves and wash the inside of the unit with a solution made of warm water and baking soda solution (2 tablespoons of baking soda to one litre of water).
- Unscrew the water reservoir at the bottom of the unit and rinse with water. To clean the outside of the unit, use a mild detergent and warm water.

Moving your cooler

To move your cooler:

- Remove anything stored inside.
- Securely tape down all loose parts located inside the unit. Turn the leveling feet up to the base in order to avoid damage. Tape the door shut.
- Be sure the cooler stays in an upright position during transportation.

5. Cigar storage guide

The ideal temperature for storing cigars is between 18 °C and 23 °C.

The ideal relative humidity (RH) for storing cigars is between 65 % and 75 % RH. To properly maintain RH in the Model Cave Cigar, you will need to include a method of adding humidity. For your convenience, a moisture container is included.

To add humidity to the unit using the included moisture container, simply fill the container with distilled water or a damp sponge wet with distilled water and place it back in the unit. Please note this water should be changed after reaching the desired humidity and refilled when used again.

Keep cigars out of direct sunlight, to avoid exposure to damaging UV rays. It is recommended to keep cigars in their original boxes and packaging as long as possible. Keep unwrapped cigars separate in your cooler to avoid unwanted mingling of flavors.

Check cigars regularly for signs of tobacco beetles and mold, and take preventative measures if necessary.

Properly stored cigars can improve with age for as long as 5-10 years, and can be kept even longer in ideal conditions.

Problem	Solution
The cooler will not operate.	<p>Check if using the wrong voltage.</p> <p>Reset the circuit breaker or check for a broken fuse.</p>
The cooler is not cold enough.	<p>Lower the temperature of the cooler .</p> <p>Open the door less frequently.</p> <p>Make sure the door is closed securely.</p> <p>Replace the seal on the door.</p> <p>Make sure there is at least 130 mm clearance between the back of the unit and any adjacent walls.</p>
The light does not work.	Contact customer support department only.
The cooler vibrates while operating.	Make sure the unit's feet are in the proper position and tightened securely.
The cooler produces a lot of noise.	<p>Make sure the product is leveled.</p> <p>Check the fan to make sure there is no debris or obstruction. If not, contact customer support department only.</p>



Scandinavian Appliances AS
Postboks 61
1740 Borgenhaugen
Norway
T: +47 815 69 117
post@norcool.no
www.norcool.no



Please visit our website for operating & installation instructions in other languages.

Version 2.0 - April 2021